



### Setting up Deluxe Rejuvenation Tube with Digital Player

Unwrap the **Deluxe Rejuvenation Tube**, use suction cup to remove Quartz Discs from top of Tube. Turn Tube on side and lower small 5/8" carbon rods and all 3 (C) **Consciousness** inserts into the quartz crystal tubes (**carbons on the bottom**). Add carbon rods and gas inserts into the two external miracoils. (**carbons on the bottom**)

- Stand Rejuvenation Tube upright and place the three 2.5" Quartz Crystal Discs on top.
- Connect the 2 pair leads from Rejuvenation Tube to + R - and - L + to the lower rear amp terminal.
- Connect 1 external Scalarcoil to + R - and 1 external Scalarcoil to - L + to the top rear amp terminal.
- Inserts 5/8" carbon rods and Inert Noble Gas into the external Scalarcoils (**carbons on the bottom**)
- Connect Digital player "Y" connectors to **Amp 1** and **Amp 2** RCA audio inputs on the Amplifiers.

Your Rejuvenation program was preloaded. Simply unlock the hold position and click play. Make sure the Rejuvenation Amplifier volume is turned to maximum. The Led's will not always flash depending on what frequencies are playing. This is normal. We have matched the sound track to the components so the system can be run 24/7. Your Sony has a battery life of around 42 hours. Simply connect to your USB port on your computer to re-charge. You can also use any regular USB charger.



Make the necessary adjustments to the amplifiers (Basic has 1 amp, Deluxe has 2 amps). Turn Treble down and Bass all the way up. Make sure the audio button is **pushed in**. Adjust the power control dial to max. Heat is no longer a problem. Some of the programs will cause the LEDs to fire while some may not depending on the frequencies that are being played. The Rejuvenation Tube contains very complex programs that introduce frequencies as low as 3 hertz. This is beyond the range of hearing but have a huge and direct influence on the brain.

### Playing your personal VAHS Frequency Program

Unplug the Digital player at the 6" Y Connector and connect the plug to the **Line-Out, not the ear phone jack** on your portable CD player. Use your VAHS software program to create your personal VAHS frequency CD. Then use the portable CD player to play your program. Re-connect Digital Player and start Rejuvenation program when finished.

### Setting up Basic Rejuvenation Tube

Unwrap the **Basic Rejuvenation Tube**, use suction cup to remove Quartz Discs from top of Tube. Turn Tube on side and lower small 5/8" carbon rods and all 3 (C) **Consciousness** inserts into the quartz crystal tubes (**carbons on the bottom**)

- Stand Rejuvenation Tube upright and place the three 2.5" Quartz Crystal Discs on top.
- Connect 1 pair of leads from Rejuvenation Tube to + R - and - L + to amp terminal.
- Connect 1 external Scalarcoil and 1 pair of leads to + R - amp terminal. Insert 5/8 carbon on the bottom.
- If you purchased an extra noble gas insert then place in this coil.
- Connect Digital player "Y" connectors to RCA audio inputs on the Amplifier as shown above.